


# BTT300



Smart GNSS/GSM/TEMINAL with  
Internal antennas, Analog input, sos  
function, RS 485 interface and Voice call.

## Overview

<b>Product Name</b>	BTT300
<b>Dimensions</b>	81(L)*43(W)*15.6(T)mm
<b>Weight</b>	49.5g
<b>Positioning Methods</b>	GPS, BDS, Glonass, QZSS, LBS
<b>Product Certification</b>	CE, FCC



# Specification


## 1 Power supply

External Power Supply	Built-in Backup Battery
9-90 VDC	140mAh Li-ion Battery


## 2 Technology

Technology	GSM
Quad Band	850MHz/900MHz/1800MHz/1900MHz
GSM Antenna	Built-in GSM Antenna
GPRS Specification	Class12
Data Path	SMS, Platforms

## 3 Ready to start




Slide to open




Assembly the SIM card and turn on the switch

## Pin Details



<b>12PIN</b>	<b>11PIN</b>	<b>10PIN</b>	<b>9PIN</b>	<b>8PIN</b>	<b>7PIN</b>
MIC-	MIC+	AIN1	DIN2(SOS)	485B	485A
<b>6PIN</b>	<b>5PIN</b>	<b>4PIN</b>	<b>3PIN</b>	<b>2PIN</b>	<b>1PIN</b>
SPK-	SPK+	DO1 (Relay )	DIN1(ACC)	GND	VCC

## Wiring Scheme



## Quick Commands

Function	SMS Command
Backend server parameter settings	SERVER,1,Domain,port,0# SERVER,0,IP,port,0#
Setting the APN	APN,<Internet Name># APN,<Internet Name>[,Username] [,User Password]# Use custom APN parameters to turn off APN adaption. APN# Query the APN parameters currently in use.
Centre number setting	CENTER, A, CENTRE NUMBER#
Enquiry Status	STATUS#
Query parameter settings	PARAM#
GPS data timing interval	TIMER,T1,T2# T1=5~60 s ; ACC ON Status Upload Interval T2=5~60 s ; ACC OFF Status Upload Interval

## LED indicator Introduction

### Orange (GSM)

Fast Flashing: GSM is initializing  
Slow Flashing: GSM signal is normal  
Always on: GPRS working  
No Flashing: No GSM Signal/SIM Card

### Blue (GPS)

Fast Flashing: Searching for GPS signal  
Always on: Position captured  
No Flashing: GPS sleep  
/ GPS not working

---

## Safety Information

This message contains information on how to operate BTT300 safely. By following these requirements and recommendations, you will avoid dangerous situations. You must read these instructions carefully and follow them strictly before operating the device!

- The device uses SELV limited power source. The nominal voltage is +12 V DC. The allowed voltage range is +9 ... +90 V DC.
- To avoid mechanical damage, it is advised to transport the device in an impact-proof package. Before usage, the device should be placed so that its LED indicators are visible. They show the status of device operation.
- When connecting the 12 connector wires to the vehicle, the appropriate jumpers of the vehicle power supply should be disconnected.
- Before unmounting the device from the vehicle, the 12 connector must be disconnected. The device is designed to be mounted in a zone of limited access, which is inaccessible to the operator. All related devices must meet the requirements of EN 60950-1 standard.

The device BTT300 is not designed as a navigational device for boats.



Do not disassemble the device. If the device is damaged, the power supply cables are not isolated or the isolation is damaged, DO NOT touch the device before unplugging the power supply



All wireless data transferring devices produce interference that may affect other devices which are placed nearby.



The device must be connected only by qualified personnel.



The device must be firmly fastened in a predefined location.



The programming must be performed using a PC with autonomic power supply.



Installation and/or handling during a lightning storm is prohibited.



The device is susceptible to water and humidity.



Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.



Battery should not be disposed of with general household waste. Bring damaged or worn-out batteries to your local recycling center or dispose them to battery recycle bin found in stores.